

Eela Audio D3 table top / 19" digital mixing console: Software update manual

D3 Remote PC software has 2 functions:

PC software to store settings in PRESET 1.

- Connect the D3 with a USB cable to the computer and start the update software.
- Click the "connect" button, upon a good connection the software will display details of the unit.
- Under pulldown menu 'System' select 'Store current settings as preset 1'



PC remote software to save settings in preset 1.

PC software to be used for firmware update. Program and update file come as a single set.

- Switch off the D3 mixing desk with the mains switch on the back.
- Turn the unit upside down
- On the bottom of the unit there is a small hole with a switch behind.
- With a small screwdriver or pin press and hold the switch while switching on the unit. The D3 is now in programming mode, the display will stay dark.
- Connect the D3 with a USB cable to the computer and start the update software.
- Click the "connect" button, upon a good connection the software will display details of the unit.
- Click "Update" and wait until the software displays a ready message.
- The D3 mixing desk will restart automatically.